



Manual

## Rooftent FAMILY



### **Dimensions and Weight**

*Inside the tent: 200 x 250 x 110 cm*

*Driving mode: 225 x 40 x 142 cm*

*Weight: 77.5 kg*

[Instruction video](#)



## Setting up Your Roof Tent:

1. Pull out the complete telescopic ladder from top of roof tent!



2. Use the ladder as a lever to press down and turn over the roof tent



3. Put the ladder to the ground and adjust the ladder length



4. Take out the adjustable supporting poles and insert the pin into the plastic clip

5. Adjust the pole length to the floor and rotate the two parts of poles up and down to lock the pole.

6. Stand on the ladder, pull out the telescopic pole of the porch and lock the pole to offer a biggest porch.



---

### Folding Down Your Roof Tent:

1. Press down two telescopic pole of the porch , lift the ladder to fold the roof tent.



2. Press the ladder's unlocking device and take it on top of roof tent.



3. Use red color rubber strip to tie the rear side of roof tent, cover the durable cover on top of it.







## Tips & Tricks

- . Always ensure the tent is dry before packing away
- . Keep the rail of the base clean and dry.

### Important Information

1. When packing away the tent, ensure there is no other objects in the tent (like sleeping bag, pillow).
2. Don't put heavy objects on the tent when the tent is closed.
3. Clean and wipe the tent with wet rag instead of machine washing or hand washing (but the cover of the mattress is washable).
4. Check the connecting points of the tents to the car; ensure all points are probably locked.
5. Please don't jump or other damaging behavior inside the tent or the car tent may probably get damaged due to uneven force.
6. Always keep the tent close when you are driving.
7. If the weather is very windy, please do not open the tent.
8. If there is abnormal noise when setting up or folding down the tent, please check the rail and all connection joints right away.

## Safety Information

- We recommend that you DO NOT drive over 70mph ( 110kmh) whilst using your rooftop tent and that you always adhere to speed limits.
- DO at the start of every journey and at regular intervals during every journey check that your roof tent is firmly fixed to your roof bars and that all of the locking straps are securely fastened. Only ever check your roof tent in a safe and suitable location.
- DO NOT use your roof tent if there is any visible damage to any part of it or its components, instead contact us to see how we can help. This is especially applicable to the locking straps and buckles.
- Understand that secured loads and incorrectly mounted roof bars can come lose during journeys and can cause serious accidents.
- Make sure that you give due consideration to the change in your vehicle height and drive behaviour (side-wind sensitivity, corner and braking behaviour).
- You must always consult your vehicle and roof bar manuals to ensure you are following their advice, these must be always be carried in your vehicle along with your roof tent safety and fitting instructions.
- Do not use bleach, alcohol or ammonia based cleaning liquids on your roof tent otherwise the surface of your roof tent may get damaged
- Please note the following when using your roof tent: –
  - The height of your vehicle can increase by up to 90cm (dependant on your roof bars).
  - Beware of low entrances, low hanging branches, etc.
  - Wind noise may be generated when travelling with a roof tent
  - When using an automatic car-wash facility your roof tent and must first be removed.